

NEWS**M1766**

To:	Sales	Category:	Phase-Out
From:	Josef Schuler	Product Group:	CBE
Date:	October 2026	Pages:	1

Phase-Out of T13 Circuit Breakers

General

In an effort to streamline our operations processes and to improve our service, we have to phase-out the **SCHURTER T13 Circuit Breaker**. This product has reached the end of its life cycle.

Thank you for your continued partnership and support. Should you have any questions or require further assistance, please do not hesitate to contact your account manager or our customer service team.

Phase-out Procedure

Last order date: 31st December 2026

Last delivery date: 31st March 2027

Activities Sales

Please inform your customers that these products will be no longer available.

Best regards,

Josef Schuler
Product Management

SCHURTER AG
www.schurter.com

List of affected part numbers of T13

Phase-Out p/n	Description	Product Hierarchy	Alternative
4411.0002	T13 Circuit Breaker 4A	040170300000008140	4410.0076
4411.0006	T13 Circuit Breaker 1A	040170300000008140	4410.0172
4411.0007	T13 Circuit Breaker 15A	040170300000008140	4410.0151
4411.0009	T13 Circuit Breaker 10A	040170300000008140	4410.0106
4411.0010	T13 Circuit Breaker 20A	040170300000008140	none
4411.0011	T13 Circuit Breaker 10A	040170300000008140	4410.0106
4411.0012	T13 Circuit Breaker 16A	040170300000008140	4410.0382
4411.0013	T13 Circuit Breaker 2A	040170300000008140	4410.0126
4411.0014	T13 Circuit Breaker 5A	040170300000008140	4410.0101
4411.0015	T13 Circuit Breaker 6A	040170300000008140	4410.0066
4411.0016	T13 Circuit Breaker 15A	040170300000008140	4410.0424
4411.0017	T13 Circuit Breaker 30A	040170300000008140	none
4411.0018	T13 Circuit Breaker 16A	040170300000008140	4410.0152
4411.0019	T13 Circuit Breaker 18A	040170300000008140	none
4411.0020	T13 Circuit Breaker 12A	040170300000008140	4410.0019
4411.0022	T13 Circuit Breaker 8A	040170300000008140	4410.0295
4411.0027	T13 Circuit Breaker 30A	040170300000008140	none
4411.0033	T13 Circuit Breaker 7A	040170300000008140	none
4411.0034	T13 Circuit Breaker 13A	040170300000008140	none
4411.0043	T13 Circuit Breaker 15A	040170300000008140	4410.0424
4411.0044	T13 Circuit Breaker 17A	040170300000008140	none
4411.0050	T13 Circuit Breaker 10A	040170300000008140	none
4411.0052	T13 Circuit Breaker 3A	040170300000008140	4410.0309
4411.0058	T13 Circuit Breaker 30A	040170300000008140	none
4411.0059	T13 Circuit Breaker 1A	040170300000008140	none
4411.0060	T13 Circuit Breaker 25A	040170300000008140	none
4411.0067	T13 Circuit Breaker 30A	040170300000008140	none
4411.0069	T13 Circuit Breaker 25A	040170300000008140	none
4411.0073	T13 Circuit Breaker 25A	040170300000008140	none
4411.0074	T13 Circuit Breaker 25A	040170300000008140	none
4411.0076	T13 Circuit Breaker 20A	040170300000008140	none
4411.0087	T13 Circuit Breaker 1A	040170300000008140	none
4411.0089	T13 Circuit Breaker 16A	040170300000008140	none
4411.0090	T13 Circuit Breaker 4A	040170300000008140	none
4411.0094	T13 Circuit Breaker 2A	040170300000008140	none
4411.0096	T13 Circuit Breaker 1.5A	040170300000008140	4410.0158
4411.0099	T13 Circuit Breaker 12A	040170300000008140	none
4411.0100	T13 Circuit Breaker 1.8A	040170300000008140	4410.0419
4411.0102	T13 Circuit Breaker 10A	040170300000008140	none
4411.0103	T13 Circuit Breaker 5A	040170300000008140	4410.0101
4411.0104	T13 Circuit Breaker 9A	040170300000008140	none
4411.0108	T13 Circuit Breaker 20A	040170300000008140	none
4411.0112	T13 Circuit Breaker 16A	040170300000008140	4410.0152
4411.0119	T13 Circuit Breaker 25A	040170300000008140	none
4411.0122	T13 Circuit Breaker 25A	040170300000008140	none
4411.0124	T13 Circuit Breaker 20A	040170300000008140	none
4411.0129	T13 Circuit Breaker 1A	040170300000008140	none
4411.0132	T13 Circuit Breaker 5A	040170300000008140	none
4411.0135	T13 Circuit Breaker 20A	040170300000008140	none
4411.0144	T13 Circuit Breaker 10A	040170300000008140	none
4411.0146	T13 Circuit Breaker 25A	040170300000008140	none
4411.0153	T13 Circuit Breaker 10A	040170300000008140	none
4411.0167	T13 Circuit Breaker 7A	040170300000008140	none
4411.0173	T13 Circuit Breaker 4A	040170300000008140	none
4411.0174	T13 Circuit Breaker 6.5A	040170300000008140	none
4411.0181	T13 Circuit Breaker 12A	040170300000008140	none

4411.0184	T13 Circuit Breaker 18A	040170300000008140	none
4411.0193	T13 Circuit Breaker 30A	040170300000008140	none
4411.0211	T13 Circuit Breaker 15A	040170300000008140	none
4411.0218	T13 Circuit Breaker 12A	040170300000008140	none
4411.0221	T13 Circuit Breaker 30A	040170300000008140	none
4411.0222	T13 Circuit Breaker 5A	040170300000008140	none
4411.0228	T13 Circuit Breaker 2A	040170300000008140	4410.0126
4411.0230	T13 Circuit Breaker 200mA	040170300000008140	none
4411.0232	T13 Circuit Breaker 800mA	040170300000008140	none
4411.0236	T13 Circuit Breaker 7.5A	040170300000008140	none
4411.0237	T13 Circuit Breaker 28A	040170300000008140	none
3-101-313	T13 Circuit Breaker 16A	040170300000008140	none