
Recommended Land Pattern

• An example of a land pattern for the Rectangular Type is shown below.




High power (double-sided resistive elements structure) type

	· · ·	7 71				
	Part No.	Size mm/inch	Dimensions (mm)			
			а	b	С	
-	ERJ2LW/2BW	1005/0402	0.52	1.4 to 1.6	0.4 to 0.6	
	ERJ3LW/3BW	1608/0603	0.5 to 0.8	2.5 to 2.7	0.9 to 1.1	
	ERJ6BW	2012/0805	0.9	3.2 to 3.8	1.1 to 1.4	
	ERJ8BW		1.2		1.3 to 1.8	
	ERJ8CW (10 to 16 mΩ)	3216/1206		4.4 to 5.0		
	ERJ8CW (18 to 50 mΩ)	3216/1206	2.0 to 2.6	4.4 to 5.0	1.2 to 1.8	

Size	Dimensions (mm)				
mm/inch	а	b	С		
0402/01005	0.15 to 0.20	0.5 to 0.7	0.20 to 0.25		
0603/0201	0.3 to 0.4	0.8 to 0.9	0.25 to 0.35		
1005/0402	0.5 to 0.6	1.4 to 1.6	0.4 to 0.6		
1608/0603	0.7 to 0.9	2.0 to 2.2	0.8 to 1.0		
2012/0805	1.0 to 1.4	3.2 to 3.8	0.9 to 1.4		
3216/1206	2.0 to 2.4	4.4 to 5.0	1.2 to 1.8		
3225/1210	2.0 to 2.4	4.4 to 5.0	1.8 to 2.8		
4532/1812	3.3 to 3.7	5.7 to 6.5	2.3 to 3.5		
5025/2010	3.6 to 4.0	6.2 to 7.0	1.8 to 2.8		
6432/2512	5.0 to 5.4	7.6 to 8.6	2.3 to 3.5		
6432/2512*	3.6 to 4.0	7.6 to 8.6	2.3 to 3.5		

* ERJL1W

• An example of a land pattern for High Power Chip Resistors / Wide Terminal Type is shown below.




Part No.	Dimensions (mm)				
	а	b	С		
ERJA1	6.4	1.70	0.60		
ERJB1 ERJC1 ⁽¹⁾	5.0	1.30	0.75		
ERJB2	3.2	0.95	0.70		
ERJB3	2.0	0.80	0.60		


(1) Anti-Sulfurated High Power Chip Resistors / Wide Terminal Type

Panasonic

Surface Mount Resistors Land Pattern



• An example of a land pattern for Chip Resistor Networks is shown below.



* When designing high density land patterns, examine the reliability of isolation among the lines and adopt the chip resistor networks.